

PLEASE FIX THIS STICKER TO THE SUNVISOR OR OTHER EASY VIEWING POSITION FOR THE DRIVER



6008 SERIES — DRIVERS SEAT ADJUSTMENT INSTRUCTIONS

**SAFETY WARNING: VEHICLE MUST BE STATIONARY
BEFORE SEAT IS ADJUSTED.**

BACKREST ADJUSTMENT

Apply slight pressure to backrest prior to releasing lever, using body weight move backrest to required position.

SUSPENSION WEIGHT ADJUSTMENT

Turn weight adjustment dial clockwise or counter clockwise to the individual drivers weight.

HEIGHT AND SLOPE

Lift rear lever and lean forward/back to adjust seat angle. Lift front lever and lean forward/back to adjust seat angle

SLIDE ADJUSTMENT

Lift slide handle to unlock and slide seat back/forward to required seated position. Release handle to lock.

AIR LUMBAR SUPPORT

Depress switches to achieve desired lumbar support.

For further information contact: ISRI SEATS on Ph 02 9756 6199
Or visit www.isri.com.au